



BNC SERIES ADAPTERS


Double BNC male
B-311 (50Ω,75Ω)




BNC male-BNC female
B-312 (50,75)




Double BNC female
B-322 (50Ω,75Ω)




Double BNC female Bulkhead receptacle
B-332 (50Ω,75Ω)




Double BNC female Bulkhead receptacle
B-332-1 (50Ω,75Ω)




Double BNC female Insulated type Bulkhead receptacle
B-0332 (50Ω,75Ω)




Double BNC female Panel receptacle
B-342 (50Ω,75Ω)




BNC male-BNC female
B-412 (50Ω,75Ω)




Three BNC male T-type
B-511 (50Ω,75Ω)




Single BNC male-double BNC female, T-type
B-512-01 / B-512-03 (50Ω,75Ω)




Single BNC male-double BNC female Special T-type
B-2512 (50Ω,75Ω)




Single BNC male-double BNC female, F-type
B-F512 (50Ω,75Ω)




Single BNC male-double BNC female
L-type B-L512
 (50Ω,75Ω)




Single BNC male-double BNC female
 (50Ω,75Ω) Y-type
B-Y512




Double BNC male-Single BNC female T-type
B-521 (50Ω,75Ω)




BNC mela-F male
BF-311 (50Ω,75Ω)




BNC female-F female
BF-322 (50Ω,75Ω)




BNC male-N female
BN-312 (50Ω,75Ω)




BNC male, Crimp type Y-type (50Ω,75Ω) for
RG58U, 59U
B-L5120




BNC male, crimp type Y-type (50Ω,75Ω) for
RG58U, 59U B-Y5120




Three BNC female T-type (50Ω,75Ω)
B-522
B-522-ZN




BNC male-F female
BF-312 (50Ω,75Ω)




BNC male-mini UHF female
BM-312 (50Ω,75Ω)




BNC male-RAC male
BR-311 (50Ω,75Ω)




BNC male-RAC female
BR-312 (50Ω,75Ω)
BR-312-ZN




BNC male-TNC female
BT-312 (50Ω,75Ω)




BNC female-TNC female
BT-322 (50Ω,75Ω)



BNC male-UHF male
BU-311 (50Ω,75Ω)



BNC male-UHF female
BU-312 (50Ω,75Ω)



BNC female-UHF female
BU-322 (50Ω,75Ω)

