



# TNC SERIES ADAPTERS


**TNC quick male-TNC female (50Ω,75Ω)**  
**T-302**




**TNC male-TNC female (50Ω,75Ω)**  
**T-312**




**double TNC female bulkhead receptacle (50Ω,75Ω)**  
**T-332**




**three TNC male T-type (50Ω,75Ω)**  
**T-511**




**double TNC male-single TNC female T-type (50Ω,75Ω)**  
**T-521**




**TNC female terminator (50Ω,75Ω,93Ω)**  
**T-612**




**double TNC male (50Ω,75Ω)**  
**T-311**




**double TNC female (50Ω,75Ω)**  
**T-322**




**TNC male-TNC female right angle (50Ω,75Ω)**  
**T-412**




**single TNC male-double TNC female T-type (50Ω,75Ω)**  
**T-512**




**three TNC female T-type (50Ω,75Ω)**  
**T-522**




**TNC male-BNC male (50Ω,75Ω)**  
**TB-311**




**TNC male-BNC female (50Ω,75Ω)**  
**TB-312**




**TNC male-F female (50Ω,75Ω)**  
**TF-312**




**TNC female-F female (50Ω,75Ω)**  
**TF-322**




**TNC male-mini UHF female (50Ω,75Ω)**  
**TM-312**




**TNC male-N female (50Ω,75Ω)**  
**TN-312**




**TNC male-RCA male (50Ω,75Ω)**  
**TR-311**



**TNC male-RCA female (50Ω,75Ω)**  
**TR-312**



**TNC male-UHF female (50Ω,75Ω)**  
**TU-312**



**TNC female-UHF female (50Ω,75Ω)**  
**TU-322**

